



Computing Services Centre  
香港城市大學  
City University of Hong Kong

# USER GUIDE FOR **USING AV EQUIPMENT**

---

Yeung Kin Man Academic Building

4/F Classrooms (P4701 & P4703)

For IT or AV support, please contact the CSC Service Desk at **3442-8340**


## AV Control Panel

### Display Source Select

1. Desktop Computer
2. HDMI Input (Use HDMI devices)
3. USB-C Input (Use USB-C devices)
4. Presentation for Visualizer

### Other Control

5. Volume Control
6. Gooseneck Mic Control (On/Off)
7. Screen Control
8. Left Projector On/Off
9. Right Projector On/Off
10. Mute Projector(s)
11. System Off
12. Help information



# Using AV Equipment

## Operation procedure of the Desktop Input




1. Press "Desktop " button
2. Select Display Devices ( BOTH/ Left Projector / Right Projector)

## Operation procedure of the HDMI Input

1. Press "HDMI " button
2. Select Display Devices ( BOTH/ Left Projector / Right Projector)
3. Connect the HDMI devices using HDMI cable

## Operation procedure of the USB-C Input

1. Press "USB-C " button
2. Select Display Devices ( BOTH/ Left Projector / Right Projector)
3. Connect the USB-C devices using HDMI cable




HDMI



USB-C

## Operation procedure of Visualizer Input

1. Press "Visualizer" button
2. Select Display Devices (Both / Left Projector / Right Projector)



## System OFF

1. Confirm Power off
2. Cancel Power off

