



Computing Services Centre

香港城市大學

City University of Hong Kong

# USER GUIDE FOR **USING AV EQUIPMENT**

---

Yeung Kin Man Academic Building

4/F Classroom P4704

For IT or AV support, please contact the CSC Service Desk at **3442-8340**


## AV Control Panel

### Display Source Select

1. Desktop Computer
2. HDMI Input (Use HDMI devices)
3. USB-C Input (Use USB-C devices)
4. Presentation for Visualizer

### Other Control

5. Volume Control
6. Gooseneck Mic Control (On/Off)
7. Screen Control
8. Left Projector (On/Off)
9. Side Left Projector (On/Off)
10. Right Projector (On/Off)
11. Side Right Projector (on/Off)
12. Mute Projector(s)
13. System Off
14. Help information



For IT or AV support, please contact the CSC Service Desk at **3442-8340**

## Operation procedure of the Desktop Input


1. Press "Desktop " button
2. Select Display Devices ( ALL/ Left Projector / Right Projector/ Left & Right Projector/ Side Left Projector / Side Right Projector )

## Operation procedure of the HDMI Input

1. Press "HDMI " button
2. Select Display Devices ( ALL/ Left Projector / Right Projector/ Left & Right Projector/ Side Left Projector / Side Right Projector )
3. Connect the HDMI devices using HDMI cable

## Operation procedure of the USB-C Input


1. Press "USB-C " button
2. Select Display Devices ( ALL/ Left Projector / Right Projector/ Left & Right Projector/ Side Left Projector / Side Right Projector )
3. Connect the USB-C devices using HDMI cable



# Using AV Equipment

## Operation procedure of Visualizer Input

1. Press "Visualizer" button
2. Select Display Devices ( ALL/ Left Projector / Right Projector/ Left & Right Projector/ Side Left Projector / Side Right Projector )



## System OFF

1. Confirm Power off
2. Cancel Power off

