



Computing Services Centre  
香港城市大學  
City University of Hong Kong

# USER GUIDE FOR **USING AV EQUIPMENT**

---

Run Run Shaw Creative Media Centre

5/F Chow Sang Sang Lecture Theatre M5050

For IT or AV support, please contact the CSC Service Desk at **3442-8340**


## AV Control Panel

### Display Source Select

1. Desktop Computer
2. Blu-ray Player
3. Presentation for Visualizer
4. Notebook Computer
5. HDMI Input (Use HDMI devices)
6. External AV Input

### Other Control


7. Volume Control
8. Projector Control
9. Room Control
10. System Off



# Using AV Equipment

## Operation procedure of the Desktop Computer Input

1. Press "PC " button
2. Select Display Devices ( Projector 1 / Projector 2 / Projector 1 & 2 / Center Projector)



## Operation procedure of the Blu-ray player Input

1. Press "Blu-ray" button
2. Select Display Devices ( Projector 1 / Projector 2 / Projector 1 & 2 / Center Projector)



## Operation procedure of the Visualizer Input


1. Press "Visualizer" button
2. Select Display Devices ( Projector 1 / Projector 2 / Projector 1 & 2 / Center Projector)



# Using AV Equipment

## Operation procedure of the Notebook Computer Input

1. Press "Notebook"
2. Select Display Devices ( Projector 1 / Projector 2 / Projector 1 & 2 / Center Projector)



## Operation procedure of the HDMI Input

1. Press "HDMI In " button
2. Select Display Devices ( Projector 1 / Projector 2 / Projector 1 & 2 / Center Projector)




## Operation procedure of the External AV Input

1. Press "AUX In " button
2. Select Display Devices ( Projector 1 / Projector 2 / Projector 1 & 2 / Center Projector)




## Projector Control

1. Left Projector Control
2. Right Projector Control



## Room Control

1. Lighting Control
2. Projection Screen Control
3. Return to Main Page



## System OFF

1. Press "YES" to confirm the system shut down
2. Press "NO" to cancel the system shut down

