



Computing Services Centre
香港城市大學
City University of Hong Kong

USER GUIDE FOR **USING AV EQUIPMENT**

LI Dak Sum Yip Yio Chin Academic Building

6/F Meeting Room LI-6372

For IT or AV support, please contact the CSC Service Desk at **3442-8340**


AV Control Panel

Display Source Select

1. Notebook computer
2. HDMI/USB-C Input (Use USB-C/HDMI devices)
3. Wireless Presentation for Apple Devices
4. Wireless Presentation for Microsoft & Android Devices

Other Control

5. Volume Control
6. Mute Display
7. Lighting Control
8. Screen Control
9. TV (On/Off)
10. Projector (On/Off)
11. VC Sound bar Control
12. System Off
13. Help information



Using AV Equipment



Operation procedure of the Notebook Input

1. Press "Notebook " button
2. Select Display Devices (Both / TV / Projector)



Operation procedure of the HDMI/ USB-C Input

1. Press "HDMI /USB-C" button
2. Select Display Devices (Both / TV / Projector)
3. Connect the device to USB-C / HDMI cable



Using AV Equipment


Operation procedure of wireless presentation for Apple Devices

1. Press "Apple Devices" button
2. Select Display Devices (Both / TV / Projector)
3. Use Screen Mirroring or AirPlay to connect Apple device



Operation procedure of wireless presentation for Microsoft & Android Devices

1. Press "Microsoft / Android Devices" button
2. Select Display Devices (Both / TV / Projector)
3. Use Screen Mirroring to connect Microsoft & Android device




Operation of Lighting Control

1. ALL ON
2. Preset 2
3. Preset 3
4. Preset 4
5. Presentation
6. Preset 6
7. Preset 7
8. Preset 8
9. Preset 9
10. ALL OFF



Operation of VC Soundbar

1. VC Soundbar On/Off
2. VC Volume Up
3. VC Volume down
4. Bluetooth
5. Mic Mute
6. Auto Framing



Using AV Equipment

System OFF

1. Confirm Power off
2. Cancel Power off

