



Computing Services Centre

香港城市大學

City University of Hong Kong

USER GUIDE FOR **USING AV EQUIPMENT**

LI Dak Sum Yip Yio Chin Academic Building

CSC Computer Theatre (LI-3610)

For IT or AV support, please contact the CSC Service Desk at **3442-8340**


AV Control Panel

Display Source Select

1. Desktop Computer
2. HDMI Input (Connect to HDMI device)
3. USB-C Input (Connect to USB-C device)
4. Wireless Presentation for Apple Devices
5. Wireless Presentation for Microsoft & Android Devices
6. Presentation for Visualizer


Other Control

7. Volume Control
8. Lighting Control
9. Screen Control
10. Projector A (On/Off)
11. Projector B (On/Off)
12. Mute Projectors
13. System Off
14. Help Information




Operation procedure of the Desktop Input

1. Press "Desktop" button
2. Select Display Devices (Both Projectors / Projector 1 / Projector 2)




Operation procedure of the HDMI Input

1. Press "HDMI" button
2. Select Display Devices (Both Projectors / Projector 1 / Projector 2)
3. Connect the device to HDMI cable




Operation procedure of the USB-C Input

1. Press "USB-C" button
2. Select Display Devices (Both Projectors / Projector 1 / Projector 2)
3. Connect the device to USB-C cable




Operation procedure of the wireless presentation for Apple Device

1. Press "Apple Devices" button
2. Select Display Devices (Both Projectors / Projector 1 / Projector 2)
3. Use Screen Mirroring or AirPlay to connect Apple device




Operation procedure of wireless presentation for Microsoft & Android Device

1. Press "Microsoft / Android Devices" button
2. Select Display Devices (Both Projectors / Projector 1 / Projector 2)
3. Use Screen Mirroring to connect Microsoft & Android device




Operation procedure of Visualizer Input

1. Press "Visualizer" button
2. Select Display Devices (Both Projectors / Projector 1 / Projector 2)



Operation procedure of Screen Control

1. Left Screen Up
2. Left Screen Down
3. Right Screen Up
4. Right Screen DOWN



Using AV Equipment

System OFF

1. Confirm Power off
2. Cancel Power off
3. After confirm ,the system will take around 15s to turn off.

